


QUICK GUIDE
RECORD SETUP
CONFIGURACIÓN DE GRABACIÓN
English / Español



ENGLISH SECTION

Once you enter to the Main Screen on your DVR, press right button on the mouse and select the third icon called Record Mode.



Then, you can select the mode you want to establish the record mode of your dvr:

Check current channel status: "●" means it is in recording status.



- ✓ Schedule: It records according to the set parameters in "Main Menu" and "record", "record plan".
- ✓ Manual: Click the "All" button and the according channel starts recording.
- ✓ Stop: Click the stop button and the according channel stops recording.

Recording Plan

Record > Record Conf.

Channel Redundancy

Length min PreRec Sec.

Mode Schedule Manual Stop

Week

	Regular	Detect	Alarm
Period 1 <input type="text" value="00:00 - 24:00"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Period 2 <input type="text" value="00:00 - 24:00"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Period 3 <input type="text" value="00:00 - 24:00"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Period 4 <input type="text" value="00:00 - 24:00"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

- ✓ Channel: Choose the corresponding channel number to set the channel. Choose the all option to set the entire channels.

- ✓ Redundancy: Choose the redundancy function option to implement the file double backup function. Double backup is writing the video files in two hard disks. When you do the double backup, make sure that there are two hard disks installed. One is read-write disk and the other is redundant disk.
- ✓ Length: Set the time length of each video file. 60minutes is default value (A maximum of 120 minutes).
- ✓ Pre Record: Record 1-30 seconds before the action.

- ✓ Mode: Set video state as Schedule, Manual and stop.
 - Schedule: Record according to the set video type (common, detection and alarm) and time section.
 - Manual: after choosing manual button, the related channel will carry common recording.
 - Stop: Click the stop button and the according channel stops recording.

- ✓ Week: set (Monday to Sunday) or full week to record, it will just record in set days.


- ✓ Period: Set the time section of common recording, the recording will start only in the set range.

- ✓ Recording type: Set recording type as regular, detection or alarm.
 - Regular: Perform the regular recording in the set time section. The video file type is "R".
 - Detect: Trigger the "motion detect", "camera mask" or "video loss" signal. When above alarm is set as opening recording, the "detection recording" state is on. The video file type is "M".
 - Alarm: Trigger the external alarm signal in the set time section. When above alarm is set as opening recording, the "detection recording" state is on. The video file type is "A".



SECCIÓN ESPAÑOL

Una vez que ingrese al Menú Principal en su DVR, presione botón derecho en el mouse y seleccione llamado "Record Mode" o Modo de Grabación.



Luego, puede seleccionar el modo en que desea establecer que grabe su equipo DVR:

Compruebe el estado actual del canal: "●" significa que está en estado de grabación.



- ✓ Programación: Graba de acuerdo con los parámetros establecidos en el Menú Principal y Registro, "Record Plan" o Plan de Grabación.
- ✓ Manual: Haga clic en el botón Todo y el canal correspondiente comenzará a grabar.
- ✓ Detener: Haga clic en el botón de parada y el canal correspondiente detendrá la grabación.

Plan de Grabación

Record > Record Conf.

Channel Redundancy

Length min PreRec Sec.

Mode Schedule Manual Stop

Week

	Regular	Detect	Alarm
Period 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Period 2	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Period 3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Period 4	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

- ✓ Canal: Seleccione el número de canal correspondiente para configurar el canal. Elija la opción "All" o Todos para configurar todos los canales.

- ✓ Redundancia: Elija la opción de opción de redundancia para implementar la función de copia de seguridad de doble archivo. Copia de seguridad doble es escribir los archivos de vídeo en dos discos duros. Cuando realice la copia de seguridad doble, asegúrese de que hay dos discos duros instalados. Uno es disco de lectura-escritura y el otro es disco redundante.
- ✓ Longitud: establece la duración de cada archivo de vídeo. 60 minutos es el valor predeterminado (un máximo de 120 minutos).
- ✓ Pre Record: Grabe 1-30 segundos antes de la acción.

- ✓ Modo: Establece el estado del video como Programación, Manual y Detener.
 - Programación: Grabe de acuerdo con el tipo de video seleccionado (común, detección y alarma) y la sección de tiempo.
 - Manual: el canal relacionado llevará una grabación común.
 - Detener: el canal correspondiente detendrá la grabación.

- ✓ Semana: Fije (Lunes a Domingo) o la semana entera para grabar, registrará sólo en los días determinados.

- ✓ Periodo: Ajuste la sección de tiempo de grabación común, la grabación comenzará sólo en el rango establecido.

- ✓ Tipo de grabación: Ajuste el tipo de grabación como regular, detección o alarma.
 - Regular: Realice la grabación regular en la sección de tiempo ajustada. El tipo de archivo de vídeo es "R".
 - Detectar: activar la señal de "detección de movimiento", "máscara de cámara" o "pérdida de video". El tipo de archivo de vídeo es "M".
 - Alarma: Activar la señal de alarma externa en la sección de tiempo ajustada. El tipo de archivo de vídeo es "A".

Any other questions you can contact our
Technical Support Department at support@logan-cam.com

Cualquier otra consulta se puede comunicar al
departamento de soporte técnico por medio
del correo: support@logan-cam.com



<http://www.logan-cam.com/>